

PREWAY WESTERN GAS SERVICE, INC.


SO WALK OVER TO THE NEWS
IN SPACE HEATING AND

Space Heating
is money



SUPPLEMENT TO
THE CHOWAN HERALD
NOVEMBER 5, 1970

PREWAY ACCESSORIES *add to your comfort*
pamper yourself with these extra conveniences





No. 487
NON-ELECTRIC
THERMOSTAT

A dependable temperature sensing device that provides automatic operation — brings heat up to preset level and maintains it. Unit attaches to oil control valve.

No. 488 WALL THERMOSTAT

Converts any heater to automatic operation, eliminates annoying temperature "swing" from too hot to too cold, with the constant irritation of continuous manual adjustment. Unit consists of attractive wall thermostat, electric top for oil valve, cable and staples. Simple to install — and plug in wall outlet.




PREWAY FUEL TANKS

Model 4495 — 5 gal. and Model 4498 — 8 gal. capacities for installation on back of heater. Heavy duty lead coated steel tank equipped with hanger brackets that fasten on back of heater. Every tank carries a fine mesh metal filter to protect against the intrusion of foreign matter when filling and a master shut-off valve. All fittings are included for connecting tank to heater.

5 gal. Model 4495 can be used on all Preway heaters.


8 gal. Model 4498 can be used on all Preway heaters except 524-524.

MOVES WARM AIR FROM ROOM TO ROOM



Model 100 TRANSAIR WALL FAN

Moves air from heater equipped room to adjacent room as indicated by diagram. Adjustable temperature control and automatic thermostat on fan. Adjustable — fits walls from 2 1/2" to 2 3/4" thick. Includes set of two rubber air filters.



PREWAY, INC.

Wisconsin Rapids, Wisconsin 54494